2018 Sportsman

#		NAME	STEPS	BOX
	CALL TO ENTER BOX			
1		½ Cuban 8 with 2 rolls on entry	• Enter level upright flight • 2 full consecutive rolls • Pull 5/8 inside loop, exiting 45’ downline • ½ roll to upright, continue 45’ downline • Pull to level flight	Center
2		Immelman	• Enter level upright flight • Roll 2 of 4 to inverted flight • Push ½ loop • End level upright flight	Left or Right
3		1 ½ Stall Spin	• Enter level upright flight • Slow to stall • 1 ½ spins on vertical downline (exit opposite of entry) • End level upright flight	Left or Right
4		?	• Enter level upright flight • Pull 5/8 inside, sharp to a 45’ upline • ½ roll to upright flight, continue 45’ upline • Pull 5/8 inside, sharp to a straight downline • Roll 2 of 8 • Pull to level flight	Center

5		Humptybump	• Enter level upright flight • Pull 90’ to straight upline • Pull 180’ to straight downline • Roll 3 of 4 • Pull 90’ to level flight • Exit level upright flight	Center
6		½ Cuban 8	• Enter level upright flight • Pull 45’ upline • Roll 2 of 4 to inverted flight, continue 45’ upline • Pull 5/8 loop to level flight • ½ roll to inverted flight • Exit level inverted flight	Left or Right
7		Loop with ½ roll What are the two lines in the circle?	• Enter level inverted flight • Push to continue inverted loop • At top of loop, ½ roll • Pull to complete loop • Exit level upright flight	Center
8		Hammerhead	• Enter level upright flight • Pull 90’ to vertical upline • Hammerhead turn to vertical downline • Full roll on vertical downline • Pull 90’ to level flight • Exit level upright flight	Left or Right

9		Sharktooth?	• Enter level upright flight • Pull 45’ upline • Pull 5/8 loop to vertical downline • ½ roll in vertical downline • Pull 90’ to level flight • Exit level upright flight	Left or Right
10		?	• Enter level upright flight • Full positive snap roll • Pull 90’ up • Push 180’ over top to straight downline • ½ roll in downline • Pull 90’ to level flight • Exit level upright flight	Left or Right
	END SEQUENCE			